

Using Your Panic Button



To activate your panic button **Press** and hold the orange button For 3 seconds

Should Your Panic button be pressed by mistake just follow the un-setting procedure



Press the Unlock button twice



The Key Pad Will display **INSERT CODE.**



Present the prox tag to the Key Pad.
(Around Number 6)

**This will stop the alarm and reset your alarm system.
If this does not work first time just repeat the un-setting procedure again**